



Basics

- care of the screen
- battery
- case



Screen Care

- Don't poke the screen
 - no pencils or pens
 - don't touch
- Use non-household cleaners

?



Battery

- Indicator Lights on Battery
- Lithium -Ion Battery
- Battery level indicator
- Can be charged while in use



Power Supply

- Little Lights

- Green

- Amber



Built to go

- Brilliant display
- Designed for durability
- Loaded with features
- Light weight starting at 4.9 pounds



The iBook Sleeve

- Extra Protection
- Turn off iBook first



The parts of the computer

- ports

- keyboard

- trackpad

- location of speakers and microphone


Ports

- First what is a port?
 - USB
 - Ethernet
 - Firewire
 - Modem





Ports



Built-in
AirPort
antenna

Security cable
lock slot

56K V.92
modem
connector

10/100
Ethernet
connector

FireWire 400
port

USB 2.0
ports

Video
output

Headphone
jack



CD Drive




- how do I insert media?
- what does it do? (plays audio & data CDs;
- how do I remove/eject the media?

Working with CDs

- inserting CDs removing CDs
 - use eject button in sidebar
 - drag CD icon to Trash / Eject Icon
 - control-click on CD icon => select Eject

iBook G4

Special Keys



Keyboard & Trackpad




Keyboard basics

- brightness (up and down using Function keys)
- volume (mute, up and down using Function keys)
- "special" keys (control, option, command/Apple, CD eject - F12)

Screen Brightness Controls

Speaker Controls



Power Button


Speaker

Eject CD




Let's Try some things

- Dimm the Screen and Brighten
- Mute and control sound
- 'sleep' the computer and wake it up



Sleeping the computer

- how do I sleep the computer?
- the flashing light indicates sleep
- what is the difference between sleeping and shutting down?



Waking up the computer

- how do I wake up the computer?
 - open lid
 - push space bar or any key

The Dock



The Dock

- where is it?
- what is it?
- making changes to the location and appearance of the Dock
- applications to the left; files, folders, etc. to the right



Show All



Displays



Sound



Network

Personal



Dock



International

Hardware



CDs & DVDs



Displays



Keyboard &
Mouse



Print & Fax



Sound

Internet & Network



.Mac



Network



QuickTime

System



Accounts



Classic



Speech



Universal
Access

Finder Basics

- open the hard drive and what do I see?
- Home Directory for Users (add "house" to Dock)
- Applications

Home ?



Save Files



- Where you save a file
- How you save a file
 - Text files
 - PDF files
 - Other Types


Backup



Restore




Restore



Home



Quick Poll



School



About This Mac
Software Update...
Mac OS X Software...

System Preferences...

Dock ▶

Location ▶

✓ At Home

At School

Recent Items ▶

Automatic

Force Quit... ⌘⌘⌘

Network Preferences...

Sleep

Restart...

Shut Down...

Log Out timwhite... ⌘⌘Q


Additional Issues

- AOL
- Special Printers



Software on your iBook


- OS X applications
- iApps
- other applications



iTunes



iPhoto



iMovie

iMovie: My First Movie 04:20 (NTSC)

Ken Burns Effect
 Start Finish
Reverse
Preview
Apply

1.32
6.26

Photo Library 8128

Wrapping Gifts Coloring Birthday Card
Gift Eggs Tasting

21:27

Clips Photos Audio Titles Trans Effects iDVD

My First Movie 04:20 (NTSC)

21:27

Zoom: Edit Volume 100% 5.1 MB 46.1 GB free

GarageBand

The screenshot displays the GarageBand interface for a project titled "My Song". The interface is divided into several sections:

- Tracks:** A vertical list on the left showing various instruments: Funky Drum Kit, Grooving Bass, Acoustic Guitar, Bongos, My Rock Guitar, Live Grand Piano, Hollywood Strings, and Master Volume.
- Mixer:** A section to the right of the Tracks, featuring volume faders and panning controls for each instrument.
- Timeline:** A horizontal axis at the top with a ruler from 1 to 14. Below it, multiple tracks show audio waveforms and MIDI regions. The tracks include:
 - Funky Drum Loop (blue)
 - Grooving Bass Loop (blue)
 - Acoustic Guitar Loop (blue)
 - Bongos Loop (blue)
 - My Rock Guitar Recording (purple)
 - Live Grand Piano (green)
 - Hollywood Strings (light green)
- Transport:** A control bar at the bottom center with buttons for play, stop, and other functions, along with a digital display showing "007.4.1001" and a tempo slider.
- Loops Browser:** A panel at the bottom left with various filter buttons (Drums, Piano, Rock/Blues, Single, Ensemble, etc.) and a search bar.
- Loops List:** A table on the bottom right showing a list of available loops with columns for Name, Tempo, Key, Beats, and Fav.

Name	Tempo	Key	Beats	Fav
Atmospheric Lead	95	G	8	<input checked="" type="checkbox"/>
Dreamy Guitar	115	E	8	<input checked="" type="checkbox"/>
Fingerstyle Line	120	A	4	<input type="checkbox"/>
Funky Wah	95	D	16	<input checked="" type="checkbox"/>
Muted Electric	90	A	8	<input type="checkbox"/>
Southern Rock Riff	112	C	16	<input type="checkbox"/>
Textural Electric	115	D	8	<input checked="" type="checkbox"/>
Vintage Guitar	125	D	16	<input type="checkbox"/>

Additional Topics

- Applications
 - iChat
 - Image Capture 'Grab'
 - Mail
 - USB keydisks



Wait till your kids
show you what
they can do!

shutdown



